VEVOR

Upgrade · The Home Creator Way

OUTDOOR FAUX ROCK COVER

MODEL: CP-65

VEVOR Support Center

CP-65

VEVOR
Upgrade·The Home Creator Way

OUTDOOR FAUX ROCK COVER

MODEL: CP-65



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

WARNING:

Read this material before using this product. Failure to do so can result in serious injury.

Assembly precautions

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble if tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. Assemble on a flat, dirt - covered garden ground surface that can safely support the Outdoor Faux Rock Cover.
8.
9. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.

Use precautions

1. DO NOT SIT OR STAND ON THIS ITEM.
2. This product is not a toy. Do not allow children to play with or near this item.
3. Do not exceed specified weight capacities.
4. Use as intended only.
5. Inspect before every use; do not use if parts are loose or damaged.

Warning-To reduce the risk of injury, user must read instructions manual carefully.

The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children shall not play with the appliance.

Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.

Please use the product according to the intended use, warn of potential injury from misuse.

Not suitable for environments with high humidity, explosive atmospheres, salt spray, acidic or alkaline conditions.

SAVE THIS MANUAL

PARTS LIST



Outdoor Faux Rock Cover *1pcs	ground stake *3pcs

ASSEMBLY STEP



Install ground stakes into the three holes of the Outdoor Faux Rock Cover and secure them to the ground.

PRODUCT PARAMETER

Model	**CP-65**
Colour	**light gray**
Desktop Size	**460×390×280mm**

