

VEVOR

Upgrade · The Home Creator Way



T35-1

VEVOR Support Center

FOLDABLE CAMPING OVEN

MODEL: T35-1

MODEL: T35-1



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

IMPORTANT SAFETY INFORMATION

Please read the following statements carefully and understand their meaning prior to use to ensure safe operation.

Symbol	Symbol Description
	Warning: To reduce the risk of injury, the user must read the instructions manual carefully.
	This symbol, placed before a safety comment, indicates a kind of precaution, warning, or danger. Ignoring this warning may lead to an accident. To reduce the risk of injury, fire, or electrocution, please always follow the recommendation shown below.

WARNING

To reduce the risk of fire, burn hazard or other injury, read this safety manual carefully and completely before using this appliance. Before cleaning, make sure the burner and oven has cooled.

DANGER: Never operate this appliance unattended. If a fire should occur, keep away from the appliance and immediately call your fire department.

DANGER: Failure to follow these instructions could result in fire, explosion or burn hazard which could cause property damage, personal injury or death.

WARNING: FOR OUTDOOR USE ONLY.

WARNING

- a. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to properly assemble or safely operate the appliance.
- b. Keep children and pets away from the appliance at all times.
- c. Do not move the appliance when in use.
- d. This appliance is not intended for and should never be used as a heater.

WARNING

1. This instruction manual contains important information required for the proper assembly and safe use of the appliance. Read and follow all warnings and instructions before assembling and using the appliance. Follow all warnings and instructions when using the appliance. Keep this

manual for future reference.

2. This manual states that an oven, fryer or broiler shall not be used on or under any apartment or condominium balcony or deck.

3. This appliance is not intended to be installed in or on a boat. This appliance is not intended to be installed in or on a recreational vehicle.

4. This appliance shall be used only outdoors, and shall not be used in a building, garage, or any other enclosed area.

5. This manual includes a list of required parts necessary for the safe operation of the appliance, directions for proper assembly and for assembly of installed parts and accessories supplied with the appliance.


6. The appliance should not be located or used under overhead unprotected flammable building materials or surfaces. For grills, fryers or griddles, the minimum clearance to any structure or combustible material should be at least 10 feet (3 metres).

SAVE THESE INSTRUCTION

Easy to Set Up



Step 1: Take out the accessories



Step 2: Lock the handle to the top



Step 3: Unfold the product



Step 4:Place the rack on the hooks on the inside sides of the product



Step 5:Turn the lock on the safety lock



Step 6: The effect picture after assembly is completed

