



Upgrade · The Home Creator Way

ABOVE GROUND FISH POND


MODEL:DS-201

VEVOR Support Center



DS-201

MODEL:DS-201



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

Safety precautions

WARNING:

Warning-To reduce the risk of injury, user must read instructions manual carefully.

The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children shall not play with the appliance.

Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.

Please use the product according to the intended use, warn of potential injury from misuse.

Not suitable for environments with high humidity, explosive atmospheres, salt spray, acidic or alkaline conditions

Parts List



	Upper Straps (with hooks) Lower Straps (without hooks)	x2 x5
	Corner Leg Poles	x 4+10
	Pond Liner	x1
	Ball Valve	x1
	Outer Corner Brackets	x4
	Center Pole Brackets	x10
	Patch kit	x1
	Width Poles	x4
	Length Poles	x4


STEP-1

Assemble the width poles and length poles




STEP-2

Assemble the Outer Corner Brackets at the four - corners.



STEP-3


Assemble the Center Pole Brackets and Corner Leg Poles.



Pay attention to the installation of Corner Leg Poles. ②-A The length at the four corners is 22.6 inches, ②-B and in the middle is 21.6 inches.

STEP-4

Upper Straps (with hooks) Lower Straps (without hooks)



Lay out the lower straps (without hooks) on the ground and then loop them onto the legs of each center - frame leg pole (corner leg poles do not use straps). Next, hook one upper strap at the center of the pond.

TEP-5

Installation is compl



The bottom of the pool should be flattened before filling it with water, as it cannot be adjusted after water is added.

Important Tips:

- 1.Extra tools will be required during assembly.
- 2.Two people are needed to assemble and move this product.
- 3.Do not let children approach this product without adult - supervision.
- 4.Do not use medications in the pond.
- 5.This product may cause drowning.



WARNING: DEEP WATER! KEEP OUT! Supervise children closely. Stay away from the pond edge. Risk of drowning.

