VEVOR

Upgrade · The Home Creator Way

WALL MOUNTED PROJECTION SCREEN

MODEL: WS120, WS72

VEVOR Support Center

WS120 **WS72**

VEVOR
Upgrade·The Home Creator Way

WALL MOUNTED PROJECTION SCREEN

MODEL: WS120, WS72



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

WARNING:

Please read this manual carefully before using the product. Failure to do so may result in serious injury.



Please read and observe carefully all the assembly instructions before beginning assembly.



Unit should be assembled by two or more people.



Please do not let your child climb on the product.If you have kids or animals who like to climb, we highly recommend using the wall anchors and brackets/straps that come with the package.

1. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children shall not play with the produce.
4. This produce shall not be used by children. Keep the appliance and its cord out of reach of children.
5. This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;

- bed and breakfast type environments.
6. Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
Please use the product according to the intended use, warn of potential injury from misuse.

ASSEMBLY PRECAUTIONS

1. Assemble only according to these instructions. Improper assembly can create hazards.

2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.

3. Keep the assembly area clean and well-lit.

4. Keep bystanders out of the area during assembly.

5. Do not assemble when tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.

7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the Wall Mounted Projection Screen.

8. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.

SAVE THESE INSTRUCTIONS

USE PRECAUTIONS

TO PREVENT SERIOUS INJURY AND DEATH FROM TIPPING:

1. This product is not a toy. Do not allow children to play with or near this item.
2. Do not exceed weight capacities, before moving.
3. Use only on a flat, hard and smooth surface capable of safely supporting a fully loaded Wall Mounted Projection Screen.
4. Use as intended only.
5. The screen can not be folded. Do not use fingers or hard objects to touch the screen surface. Do not splash the milk, fruit juice or other chemical doses to the screen surface. Keep the screen far away from the high temperature objects or fire.
6. If the screen is dirty,please wash the screen gently by a broom or a cotton ball, do not use the organic solvents to clean the screen surface.
7. When pulling the screen down, must be slowly and vertical. Do not pull it roughly, please stop pulling as soon as the black border is out or the screen will be jammed or injured, then send the screen to the maintenance center.

8. After using, put the screen back to the housing in order to avoid being polluted, If not using it for a long time, please take the screen from the wall and pack it in a carton.

Inspect before every use; do not use if parts are loose or damaged.


TECHNICAL SPECIFICATIONS

Model	WS120	WS72
Screen Size	120 inch, 1:1	72 inch, 4:3
Product Dimensions (LxWxH)	2275*90*2340mm	1565*1255*70mm
Net Weight	About 7.8kg	4.45kg

*Products such as specifications, appearance, and design are subject to modification without prior notice.

PACKAGE CONTENTS

MODEL NO.: WS120, WS72



Manufacturer: Shenzhen Future Information Technology Co.,Ltd
Address: No.15 Dayang Industrial Zone lougang Village Songgang town Bao'an District ShenZhen China
E-mail: support@vevor.com

