



Upgrade · The Home Creator Way

Boat Bimini Top

MODEL:

3 BOW 6'L×46"H ×73"-78"W

3 BOW 6'L×46"H ×79"-84"W

3 BOW 6'L×46"H ×85"-90"W

VEVOR Support Center


1	3 BOW 6'L×46"H ×73"-78"W Pacific Blue		4	3 BOW 6'L×46"H ×79"-84"W Light Grey	
2	3 BOW 6'L×46"H ×73"-78"W Light Grey		5	3 BOW 6'L×46"H ×85"-90"W Pacific Blue	
3	3 BOW 6'L×46"H ×79"-84"W Pacific Blue		6	3 BOW 6'L×46"H ×85"-90"W Light Grey	

MODEL:

3 BOW 6'L×46"H ×73"-78"W

3 BOW 6'L×46"H ×79"-84"W

3 BOW 6'L×46"H ×85"-90"W



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

IMPORTANT SAFEGUARDS



WARNING: Read and understand this entire manual before operating or servicing this product. Failure to follow these warnings and instructions can cause personal injury or damage to valuable property.

1. This product is not a toy. Avoid children using and playing with it.
2. Keep away from sharp points, blades and other items.
3. Keep away from open flame. This product will ignite and burn if brought into contact with an open flame.
4. The product complies with relevant standards and regulations.
5. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas.
6. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Never smoke under the canvas.
8. Never use candles, matches, or any type of open flame under the canvas.
9. Never cook under the canvas.
10. Never store flammable liquid under the canvas.
11. Never refuel lanterns, heaters, or stoves under the canvas.
12. Do not set up the canvas when the temperature is below freezing.
13. Cleaning and user maintenance shall not be performed by unsupervised children.
14. This product is not recommended for use during thunderstorms.
15. Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it
16. Please use the product according to the intended use, warn of potential injury from misuse.

Installation precautions.

1. Installation only according to these instructions.
2. Keep installation area clean and well-lit.
3. Keep bystanders out of the area during assembly.

4. Do not install when tired or when under the influence of alcohol, drugs or medication.
5. Product capabilities apply to properly and completely installed products only.
6. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area. Please keep small spare parts out of children's reach.
7. Installation and disassembly by two people is safer and easier. Please consult the owner's manual.

CAUTION:

- Please use the boot to protect the fabric when the bimini top is not in use.
- Please fold the bimini top when the vessel speed exceeds 45MPH.

Note: Please check if all parts are in before assembly.

SAVE THESE INSTRUCTIONS

PACKING LIST


No.	Picture	Component	Label	QTY	Remark
1		Long Bow(1185mm)	L	1	Pipe No. 1 and Pipe No. 2 are connected, with the spring clips facing the same direction.
2		Mid Bow(1085mm)		1	Pipe No.2 and Pipe No.1 are connected, with the spring clips facing the same direction.
3		Short Bow(435mm)		1	Pipe No. 3 and Pipe No. 1 are connected, with the spring clips facing the same direction.
4		Long Bow(1185mm)	R	1	Pipe No. 4 and Pipe No.5 are connected, with the spring clips facing the same direction.

5		Mid Bow(1085mm)		1	Pipe No. 5 and Pipe No. 4 are connected, with the spring clips facing the same direction.
6		Short Bow(435mm)		1	Pipe No. 6 and Pipe No. 4 are connected, with the spring clips facing the same direction.
7		Support Pole	/	2	Tube No. 7 is connected to Tube No. 1 and Tube No. 4 respectively.
8		Crossbars	/	3	Tubes No. 8 and No. 9 are connected at the letterhead.
9		Crossbars	/	3	
10		Tent	/	1	/
11		Stainless Steel Saddle	/	4	/
12		Self Tapping Screw	/	16	/
13		Straps with Stainless Steel Hook & Webbing Adjuster	/	4	/
14		Storage Boot	/	1	/
15		Pole Base	/	4	/


ASSEMBLY INSTRUCTIONS

1. Open the package and check the product.


Assemble the left and right section of the frame, as shown in the below figure.



2. Insert the 3 connected tubes through the tent.




3. Assemble the left and right side of the frames




The support pole is divided into L and R strapping, assembly can not be confused, the connection hole spring attention needs to be in the same direction.

Please note that we have pasted L and R stickers on the frame to help you distinguish left from right. The labeled tube represents assembly on the front side of the label.

4. Distinguish the front from rear according to " Front" label, then connect the side frames to top tubes.




5. Connect the bolt head to the long pole and to the mid pole, shown as the below figure.



Connect the top of the adapting piece (on the mid bow) to the webbing, as shown in the figure.

6. Install the stainless steel saddle onto the boat's rail. Secure the sidewall by fastening the webbing at both sides to the stainless steel saddle. Repeat the same operation for the other sidewall.



Install the stainless steel saddle. Pre-drill holes with drill bits no larger than 3.8mm on the ship deck for easier installation.

