



Upgrade · The Home Creator Way

UNIVERSAL TV STAND


MODEL:YBTC-03

VEVOR Support Center



YBTC-03

MODEL:YBTC-03



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

WARNING:

Before installation, please ensure that your TV stand mounting holes, dimensions, and weight can meet the specifications and standards of the TV stand. If you have any questions or questions about the instructions and warnings, please contact us for help..



Important:

1. When installing the support, please use professional safety devices and tools in accordance with the requirements of the assembly instructions. Improper installation may cause the TV to fall or serious injury.
2. Before installation, ensure that the support surface can safely support the weight of the device and all accessories.
3. Please do not exceed the intended load capacity, otherwise it may cause serious injury or property damage.
4. This product contains small parts, swallowing them may cause choking hazards. Please keep out of reach of children.
5. This product is only suitable for indoor use, outdoor use may cause product damage and personal injury risk.
6. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children shall not play with the appliance.
9. This appliance shall not be used by children. Keep the appliance out of reach of children.

10. This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
11. Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
12. Please use the product according to the intended use, warn of potential injury from misuse.

Maintenance:

Please check the connection between the bracket and the TV periodically to ensure it remains stable, and verify that the screws have not loosened or fallen off due to long-term use (at least once every three months). If any security risks are identified, replace or reinforce the parts promptly.

SAVE THIS MANUAL

PARTS LIST (TV STAND)

Install parts

(Be sure to check that the parts are complete before installation, and contact your supplier if they are missing or damaged.)

A	 M8*16 2pcs	 Gasket 2pcs
B	 M6*12 11pcs	
C	 M6*12 4pcs	 Gasket 4pcs
D	 Knob(M6*20) 2pcs	
E	 Hex Key(M4) 1pc	 Hex Key(M5) 1pc
		 Open End Wrench 1pc
	 Pulley 4pcs	

ASSEMBLY STEP

STEP1 (Install the Base)




Pulley Open End Wrench
4pcs

Assemble the lower post and pulley

STEP2 (Install the Base)





A M8*16 A Gasket Hex Key
2pcs 2pcs




Install the base bar and base

STEP3 (Install the Base)

Shelf installation



② Assemble the storage board and the cavity board together



STEP4 (Erection of Upper Column)

Install the base bar and base



C M6*12
4pcs




C Gasket
4pcs



Hex Key



Insert the upper post into the lower post




STEP5 (Erection Of Upper Column)

Install knobs



D M6*20

2pcs



PARTS LIST (TV SCREW FITTINGS)

				
M4*30 B1 X4	M6*16 B2 X4	M6*35 B3 X4	M8x16 B4 X4	M8x35 B5 X4
				
M8x50 B6 X4	SP1 B7 X4	SP2 B8 X4	Three Hole Gasket B9 X4	

STEP6 (Hook Installation)




Figure A








Figure B


Install the TV heightening pad, which can be installed in the middle of the hook and the TV (as shown in Figure A) or above the hook (as shown in Figure B) according to the demand.




Note: The screws should not be too short or too long when installing, and the long screws can be installed between the hook and the TV.

When installing B1-B6 screws, use them according to the actual requirements. Select gaskets based on the screw type. Using increasing pad according to the actual requirements or do not install them.

STEP7 (The TV is Mounted on the Panel)



Hang the TV on the TV stand and tighten the safety screws



PRODUCT PARAMETER

Model	YBTC-03
Safe Loading Weight	Overall 250 LBS TV Position: 205 LBS Pallet: 45 LBS
Product Size	995*463*(1578-1378)mm

