VEVOR

Upgrade · The Home Creator Way

PROJECTION SCREEN

USER MANUAL

MODEL NO.: ZG-LJ120、ZG-LJ150


VEVOR Support Center

ZG-LJ120 **ZG-LJ150**

VEVOR
Upgrade·The Home Creator Way

Projection Screen

MODEL NO.: ZG-LJ120、ZG-LJ150



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

⚠WARNING:

Please read this manual carefully before using the product. Failure to do so may result in serious injury. SAVE THIS MANUAL


1.The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
2.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3.Children shall not play with the appliance.
4.This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
5.This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.
6.Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
Please use the product according to the intended use, warn of potential injury from misuse.

1. The screen cannot be folded. Do not use fingers or hard objects to touch the screen surface. Do not splash milk. fruit juice or other chemical doses to the screen surface. Keep the screen far away from high temperature objects or fire.
2. If the screen is dirty, wash it gently with a clean cloth or a cotton ball. Do not use organic solvents to clean the screen surface.
3. When pulling the screen down. it must be done must be slowly and vertically. Do not pull it roughly. Stop pulling as soon as the black border is out or when the screen is jammed. Send the screen to the service center if the jammed is permanent.
4. After using, retract the screen back to the housing in order to prevent dirt. If not using it for a long time, please remove screen from the wall and pack it in a carton.

TECHNICAL SPECIFICATIONS

Model	ZG-LJ120	ZG-LJ150
Main Material	Steel	Steel
Screen Size	120 inch, 16:9	150 inch, 16:9
Product Dimensions(LxWxH)	3450*650*2286 mm	4202*650*2746 mm
Packing Size(LxWxH)	860*185*160 mm	860*185*160 mm
Net Weight (kg)	5	6.1
Gross Weight (kg)	5.7	6.8


PACKAGE CONTENTS



A tripod	X2	B vertical bar	X2
C Plastic ring connector	X2	D crossbar	X2
E 90 ° connector	X2	F curtain	X1
G rope	X2	H ground spike	X4

ASSEMBLY STEPS


STEP1



X2

TaketheaccessoryBandassembletwogroupsasshowninthe figure.


STEP2



Connect the fitting C with the tube instep1B，and insert the fittingC into the tubeB.Repeattheabove.

X2


STEP3



Take the accessory e and assemble the accessory e to step2,asshownin the figure. Repeattheabove.

X2

STEP 4




Take the fitting D and assemble it as shown in the figure.

STEP 5




Take the two cross bars d from step 4 and thread them into the black sleeve of the curtain.

STEP 6




Connect the D tube with the curtain on to the upper plastic part [in step3,and the other D tube to the lower plastic part C instep3,as shown in the figure.

STEP 7




Take the fitting A and assemble it to the bottom of the pipe B.

STEP 8



Paste the hook and loop on the curtain in sequence,adjust the position of the plastic part C,and tighten the screws on the plastic part C to complete the installation after ensuring that the curtain picture is in the beststate.

STEP 9



Tips: If it is used outdoors, the accessories G/H can be used to stabilize the shelf as shown in the figure

COMPLETION

