



Upgrade · The Home Creator Way

ROTATING SHOE RACK TOWER

MODEL: OY-XZXJ-05-7

Rotating shoe rack tower assembly video:

<https://d2qc09rl1gfuof.cloudfront.net/product/XZXJEKDLK7CSAC5US001/Rotating+Shoe+Rack+Tower+Assembly+Steps.mp4>




VEVOR Support Center



OY-XZXJ-05-7

MODEL:OY-XZXJ-05-7




This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

WARNING:

Read this material before using this product. Failure to do so may result in serious injury.

	Please read and observe carefully all the assembly instructions before beginning assembly
	Unit should be assembled by two or more people
 DO NOT CLIMB	Please do not let your child climb on the product

Assembly precautions

1. Assemble only according to these instructions. Improper assembly may create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble if tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the rotating shoe rack tower.
8. It is recommended that assembly is undertaken by at least 2 adults.
9. If possible, you can use power tools to make assembly easier.


10. Please note that some types of parts have a spare.
11. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.
12. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.










Use precautions

1. This product is not a toy Do not allow children to play with or near this item.
2. Do not exceed specified weight capacities.
3. Use only on a flat, level, hard, and smooth surface that can safely support a fully loaded Rotating shoe rack tower.
4. Inspect before every use; do not use if parts are loose or damaged.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
6. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
7. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
8. Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
9. Please use the product according to the intended use, warn of potential injury from misuse.

SAVE THIS MANUAL


PARTS LIST




A X1 	B X1 	C X1 
D X6 	E X6 	F X6 
G X1 	H X4 	I X1 
J X60  M4*25	K X20  M4*10	L X1 

ASSEMBLY STEP

STEP 1



STEP 2




STEP 3

NOTES:

All casters are fixed with screw K.

The disc and vertical plate are fixed with screw J.




J x8

K x20


Note: The middle caster wheel does not have a brake.

STEP 4




STEP 5

All the notch faces
downward.



Note: The same combination has 6.


STEP 6




Note: The same combination has 6.

J x24

STEP 7




STEP 8



STEP 9


Note:

All the notch faces downward.



J x4


STEP 10



Fix the laminates with screws J at each notch.

J x24

STEP 11



TIPS:

- If you need to rotate or move the shoe rack, you must first release the caster brakes.
- To ensure the stability of the product, it is recommended not to disassemble it frequently.
- It is suggested to place the shoes in a horizontal staggered manner. For large-sized shoes, there may be a problem of incompatibility.

PRODUCT PARAMETER

Model	OY-XZXJ-05-7
Main Color	White
layers	Seven
Load-bearing capacity per floor	26.46 lbs
Product Size(W*D*H)	598*598*1670mm
Net Weight	17.1 kg

* Products such as specifications, appearance, and design are subject to modification without prior notice.

