印刷制作说明（非印刷页）

叶子类目	投影屏幕
厂家型号	DZC-60
子 SKU	TYPMDZCY60169TJZJV0
厂家型号	DZC-70
子 SKU	TYPMDZCY70169BAL0V0
厂家型号	DZC-80
子 SKU	TYPMDZCY80169V6FXV0
厂家型号	DZC-90
子 SKU	TYPMDZCY901696BAVV0
厂家型号	DZC-100
子 SKU	TYPMDZC10016968W7V0
厂家型号	DZC-110
子 SKU	TYPMDZC110169N4Z0V0

技术要求:

1.内容正确，图文清晰，位置准确：

2.成品不准有破损、裂纹污迹等影响美观缺陷；

3.具体页数、尺寸、内容、字体、字号、按设计图纸；

4.A5 版面双面黑白印刷，80g 以上铜版纸或者双胶纸。

5.装订方式骑马订/折页或者胶装，。

6.打样确认后方可批量印制。

VEVOR Support Center

1	DZC-60		4	DZC-90	
2	DZC-70		5	DZC-100	
3	DZC-80		6	DZC-110	

VEVOR

Upgrade · The Home Creator Way

PROJECTION SCREEN

USER MANUAL

MODEL NO.: DZC-60, DZC-70, DZC-80, DZC-90, DZC-100, DZC-110

VEVOR
Upgrade·The Home Creator Way

Projection Screen

MODEL NO.: DZC-60, DZC-70, DZC-80, DZC-90, DZC-100, DZC-110



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

⚠WARNING:

Please read this manual carefully before using the product. Failure to do so may result in serious injury. SAVE THESE INSTRUCTION

ASSEMBLY PRECAUTIONS

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble when tired or under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the Projection Screen.
8. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.
9. The warranty will only be valid if you follow the instructions below carefully! Improper use and care may cause serious injury and/or damage!
10. Make sure the surface you have chosen for installing the screen is flat and secure.. Please read the following as any damage to the screen surface will impact the image's quality:

A. Do not touch the screen surface by hand.
B. Do not write or draw on the screen surface.
C. Do not poke the screen surface with finger or edge tools as it may cause scratches or tears.

11. Retract the screen after every use.
12. Do not pull two sides of the screen fabric by hands, do not fold the screen fabric.

13. To prevent unnecessary damage, the operation and maintenance of the screen should be done by adult.
14. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.



Ignoring the safety warnings may lead to injuries or damaging the product.



Retract the screen after every use.Leave it hanging for along period may cause screen fabric loose.



Avoid hanging anything on the screen as it may cause the screen to fall down.



The screen should be installed at secure place to avoid any accidents or the screen falling down



Loose parts may cause the screen fall down.

USE PRECAUTIONS

TO PREVENT SERIOUS INJURY AND DEATH FROM TIPPING:

1. DO NOT SIT OR STAND ON THIS ITEM.

2. This product is not a toy. Do not allow children to play with or near this item.
3. Use only on a flat, level, hard and smooth surface capable of safely supporting a fully loaded Projection Screen.
4. Use as intended only.
5. Inspect before every use. Do not use if parts are loose or damaged.
6. Clear out an area to assemble the screen. Make sure the area is larger than the size of the screen.
7. Remember that the assembly will require at least two people for some steps.
8. Do not assemble in areas with a high temperature to avoid damaging

the screen.

9. Read through this entire Assembly Guide before.
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
11. Children shall not play with the appliance.
12. This appliance is intended to be used in household and similar applications such as:
    - Staff kitchen areas in shops, offices and other working environmen;
    - By clients in hotels, motels and other residential type environments;
    - For courseware display and lecture live streaming in classrooms, lecture halls and training institutions;
13. Please use the product according to the intended use, warn of potential injury from misuse.

SAVE THESE INSTRUCTIONS

TECHNICAL SPECIFICATIONS

Model	DZC-60	DZC-70
Screen Size	60 inch, 16:9	70 inch, 16:9
Product Dimensions (LxWxH)(mm)	1350*2320	1630*2320
Packing Size (LxWxH)(mm)	725*135*95	725*135*95
Net Weight (kg)	About 1.9	About 2.2
Gross Weight (kg)	About 2.3	About 2.5

Model	DZC-80	DZC-90
Screen Size	80 inch, 16:9	90 inch, 16:9
Product Dimensions (LxWxH)(mm)	1840*2320	2025*2320
Packing Size (LxWxH)(mm)	725*140*95	725*155*115
Net Weight (kg)	About 2.4	About 2.6
Gross Weight (kg)	About 2.7	About 2.9

Model	DZC-100	DZC-110
Screen Size	100 inch, 16:9	110 inch, 16:9
Product Dimensions (LxWxH)(mm)	2270*2320	2470*2320
Packing Size (LxWxH)(mm)	725*155*115	725*155*115
Net Weight (kg)	About 2.9	About 3
Gross Weight (kg)	About 3.2	About 3.3

PACKAGE CONTENTS



Stand

top pole

bottom pole

metal hanging part connector and plastic clip

fabric screen

ASSEMBLY STEPS

STEP1

- assemble the top and bottom horizontal poles and slide the poles through the fabric screen pole pocket





STEP2

- use the plastic U-shaped clips to fix the fabric screen with the top and bottom poles on each end.





STEP3

- fix the metal hanging part on the top pole make sure it is in the middle position to keep balance, then hang on the top of the stand.





STEP4


- adjust the stand height and use the connector to fix the bottom pole on the stand.





Note: this product is suitable for dark environment for a better projection effect

COMPLETION



欧英代粘贴处

(这部分内容不印刷，直接粘贴欧英代贴纸)

