



Affordable. Reliable. Home Improvement.

POP UP GAZEBO SCREEN TENT

**Model: FY10X10Military Green-6 / FY12X12Brown-6 /
FY12X12Smoky Gray-6 / FY12X12Military Green-6 /
FY15X15Brown-8**

VEVOR Support Center

1	FY10X10Military Green-6		4	FY12X12Military Green-6	
2	FY12X12Brown-6		5	FY15X15Brown-8	
3	FY12X12Smoky Gray-6				

VEVOR

Affordable. Reliable. Home Improvement.

POP UP GAZEBO
SCREEN TENT

MODEL:FY10X10Military Green-6 / FY12X12Brown-6 / FY12X12Smoky Gray-6
/ FY12X12Military Green-6 / FY15X15Brown-8



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

WARNING:

Read this material before using this product. Failure to do so can result in serious injury.

Assembly precautions

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble if tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.

SAFETY INFORMATION

The tent was not tested for wind and snow loads, unless that is clearly indicated otherwise. Therefore, these loads are not covered by guarantee. Please watch the weather forecasts to be able to properly protect or disassemble the tent before problems appear. Tents should only be used as temporary accommodation and should be disassembled in adverse weather conditions.

Make sure to keep sufficient distance to houses as well as gas and power lines to avoid possible damage. Please check the area for power cables and gaslines. Ask your local authority for further information if needed.

When making use of suitable heaters, keep a minimum distance of 1.2 m to tarp material. Open fire or heaters with open flames such as patio heaters, umbrella heaters, gas heaters etc. should NOT be used inside the tent in any case.

SPECIFICATIONS

Model	FY10X10Military Green-6
Product Size	10×10ft
Color	Military green/Beige







Model	FY12X12Brown-6
Product Size	12×12ft
Color	Brown/Beige

Model	FY12X12Smoky Gray-6
Product Size	12×12ft
Color	Smoky Gray/Beige


Model	FY12X12Military Green-6
Product Size	12×12ft
Color	Military Green/Beige

Model	FY15X15Brown-8
Product Size	15×15ft
Color	Brown


PARTS LIST

Serial number	Quantity	Part picture	Name
#1	x1		Tent
#2	x1		Rain cloth
#3	x2		Door pole
#4	x1		Door crossbar
#5	x3		Top pole
#6	x2		Irons
#7	x7		Camp rope
#8	x13		Camp nail
#9	x1		Carrying Bag
#10	x1		Pole Bag
#11	x1		Pegs & Ropes Bag
#12	x2		Tying rope


ASSEMBLY STEP







Open the packaging and remove the tent(#1) and accessories.




Spread out the tent, find the pull rope in the middle of one side (as shown in the picture), and pull it up.




According to the second step, continue to pull apart the other sides.



First, fix the two corners with the ground and rope. Use aids to secure the tent in position, then a person take the 3pcs top pole out of the bag and unfold. Walk into the screen house and place the unfolded pole into the pockets at the top and then push the pole's centre part up.






Fix the corners with ground nails, tie the camp ropes, and then fix them with ground nails.




Take out iron from the bag and unfold and splice them, support the curtain to get a canopy foyer, fix the corners with ground pegs, tie the camp rope, and then fix it with ground nails.




Cover the rain cloth(#2) over the top of the Pop-up Gazebo Screen Tent and hang up the hooks on the rain cloth.


Storage instructions STEP



After removing accessories such as ground nails, camp ropes, fiber poles, and covers, first enter the tent and drag the top down. Then, press each side inward and fold the bracket together.



After fully folding and closing, tie the folded tent tightly with tying ropes.



Put the folded tent and accessories into a storage bag to complete storage.

Manufacturer: Shanghaimuxinmuyeyouxiangongsi

Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD NSW 2122 Australia

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

UK	REP
-----------	------------

YH CONSULTING LIMITED. C/O YH Consulting
Limited Office 147, Centurion House, London
Road, Staines-upon-Thames, Surrey, TW18 4AX

EC	REP
-----------	------------

E-CrossStu GmbH
Mainzer Landstr.69,
60329 Frankfurt am Main.

