VEVOR

Upgrade · The Home Creator Way

PROJECTION SCREEN WITH STAND

MODEL: TS60H, TS84H, TS7070


VEVOR
Support Center

TS60H **TS84H** **TS7070**

VEVOR
Upgrade·The Home Creator Way

Projection Screen with Stand

MODEL: TS60H, TS84H, TS7070



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

⚠ **WARNING:**

Please read this manual carefully before using the product. Failure to do so may result in serious injury. SAVE THESE INSTRUCTION

ASSEMBLY PRECAUTIONS

1. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children shall not play with the appliance.
4. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
5. Assemble only according to these instructions. Improper assembly can create hazards.
6. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
7. Keep the assembly area clean and well-lit.
8. Keep bystanders out of the area during assembly.
9. Do not assemble when tired or under the influence of alcohol, drugs or medication.
10. The product capabilities apply to properly and completely assembled products only.
11. Assemble on a flat, level, hard and smooth surface capable of safely supporting the Projection Screen with Stand.
12. This appliance is intended to be used in household and similar

applications such as:

- business meetings and conferences;
- classroom teaching and training sessions;
- home theaters and outdoor entertainment.

13. Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
14. Please use the product according to the intended use, warn of potential injury from misuse.
15. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.

USE PRECAUTIONS

TO PREVENT SERIOUS INJURY AND DEATH FROM TIPPING:

1. DO NOT SIT OR STAND ON THIS ITEM.

2. This product is not a toy. Do not allow children to play with or near this item.
3. Use only on a flat, level, hard and smooth surface capable of safely supporting a fully loaded Projection Screen with Stand.
4. Use as intended only.
5. Inspect before every use. Do not use if parts are loose or damaged.
6. The screen can not be folded. Do not use fingers or hard objects to touch the screen surface. Do not splash the milk, fruit juice or other chemical doses to the screen surface. Keep the screen far away from the high temperature objects or fire.
7. If the screen is dirty,please wash the screen gently by a broom or a cotton ball, do not use the organic solvents to clean the screen surface.
8. After using, put the screen back to the housing in order to avoid being polluted, If not using it for a long time, please take the screen from the wall and pack it in a carton.
9. When pulling the screen down, must be slowly and vertical. Do not pull

it roughly, please stop pulling as soon as the black border is out or the screen will be jammed or injured.then send the screen to the maintenance center


TECHNICAL SPECIFICATIONS

Model	TS60H	TS84H
Product Dimensions (LxWxH)(mm)	1460*720*(1350-1810)	2010*640*(1650-2110)
Net Weight(kg)	About 4.65	About 6.2

Model	TS7070
Product Dimensions (LxWxH)(mm)	1930*890*(2400-2640)
Net Weight(kg)	About 7.4

*Products such as specifications, appearance, and design are subject to modification without prior notice.

STRUCTURE



Choose a suitable place for installing,open the tripod feet first,pull out the upper bar to a suitable height and lock it,hang the pulling rod above to the goose neck and adjust the screen height,then finally fix/lock it at a satisfied position which you want.After using,release the screen and put it back to the housing.

