



Upgrade · The Home Creator Way




WZ600 WZ601

VEVOR Support Cen

PATIO DINING TABLES


MODEL:WZ601/WZ600







MODEL:WZ601/WZ600



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

1



Warning-To reduce the risk of injury, user must read instructions manual carefully.

UNPACKING INSPECTION MATTERS

Each bar stool undergoes strict factory testing before leaving the factory. After opening the packaging, please perform the following inspection steps:

- Whether the product is damaged;
- Is the product model consistent with your order;

If you find any omissions or damages, please contact your supplier as soon as possible.

SAFETY WARNINGS AND PRECAUTIONS

Thank you for choosing this product. To ensure that you can use it correctly, please carefully read the instruction manual before operation and keep it properly for future reference. Please be sure to read the precautions and safety rules in this page to ensure your safe use. This manual will outline safety warnings and precautions, operating, maintenance and cleaning. The warnings and instructions reviewed in this manual cannot cover all possible conditions and situations that may occur. Caution and common sense are not built into this product, since we believe that the uses will comply with these codes.

Please read all instructions before using the product.

- The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Keep the product away from fire .
- Do not place any hot objects on the surface of the product .


CLEANING AND STORAGE

- Wipe with a soft, dry cloth. Never use an abrasive cleanser or harsh pad.
- Try to minimize the use of water, regularly wipe with a slightly damp cloth dipped in mild detergent, then dry and polish the surface with a clean soft cloth.
- To clean the fine seams of the table, you can use a honey powder brush to brush out the dirt inside the seams, and then use a vacuum cleaner to clean them up.
- Children are not allowed to wipe the product to avoid tipping and falling injuries.
- After the product is disassembled, please put the parts and accessories together.
- Re-tighten bolts every 3 months by using the enclosed allen-key.

*Using an electric drill can damage the chair.Please re-tighten bolts manually.


2

STEP 3



Lock legs B and table top A with hexagon socket screws D and washers F. Use 8 hexagon socket screws D and 8 washers F.

STEP 4



Installing the umbrella hole ring into the hole in the middle of the desktop can accommodate a sunshade with a handle diameter of 38. If the umbrella hole ring is not used, a sunshade with a handle diameter of 48 can be used.

6

4. If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us .

5. Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage .

6. Please do not stand on the desktop.

7. Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges .

8. Please match the corresponding part and fitting based on the part number in the manual .

9. If the part does not match with the fitting, please check the piece as specified in this manual .

10. During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one. Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity .

11. Please place this item on level, solid ground during use.

WARNINGS

- This product is not a toy. Please keep the product away from children while assembling.
- Use as intended only. Do not let children play or jump on the product. Do not stand on the item or use as a step ladder.
- Inspect before every use. Do not use it if parts are loose or damaged.
- Tighten the lower screws every three months to prevent loosening of the legs.
- The total maximum static load capacity of the product is 150 LB (68 KG). Do not exceed the listed weight capacity. Tighten all knobs securely before applying load. Be aware of dynamic loading! The sudden load movement may briefly create an excess load, causing product failure.





3

PRODUCT RELATED PARAMETERS


Model	Product size	Material	Main colors	Loading Capacity	Umbrella hole size
WZ601	1200*725mm	Carbon steel	Black	150LB	38mm*48mm
WZ600	1035*720	Carbon steel	Black+Grey wood grain	150LB	38mm*48mm

INSTALLATION STEPS

PART LIST


A  Table Top 1pcs	B  Leg 4pcs	C  Metal center ring 1pcs
D  Hexagonal socket screw M6x15 8pcs	E  Hexagonal socket screw M6x25 8pcs	F  Washer 16pcs
G  Umbrella hole cover 1pcs	H  Umbrella hole ring 1pcs	I  Hex wrench 1pcs

STEP 1



Two table tops A facing each other, waiting to be used.

STEP 2



Lock legs B and metal center ring C with hexagon socket screws E and washers F. Use 8 hexagon socket screws E and 8 washers F. (*Reminder - Do not completely tighten the bolts now.Repeat this step until all the Table Legs B are connected to the Table Top A, then tighten all the bolts.)

5