VEVOR

Upgrade · The Home Creator Way

MODEL: 3323

MODEL: 3323-W

MODEL: 3324-W

VEVOR Support Center


Storage Drawers

MODEL: 3323,3323-W,3324-W


VEVOR | Upgrade
The Home Creator Way

STORAGE DRAWERS


MODEL: 3323,3323-W,3324-W



3323



3323-W



3324-W

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

WARNING:

Read this material before using this product. Failure to do so may result in serious injury.

Assembly precautions

1. Assemble only according to these instructions. Improper assembly may create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble if tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the Storage Drawers.
8. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.
9. The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
11. Children shall not play with the appliance.
12. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.

13. This appliance is intended to be used in household and similar applications such as:
    – staff kitchen areas in shops, offices and other working environments;
    – farm houses;
    – by clients in hotels, motels and other residential type environments;
    – bed and breakfast type environments.
14. Please properly keep pro duct. Check whether the product is abnormal before use. If it is abnormal, please stop using it.
15. Please use the product according to the intended use, warn of potential injury from misuse.

Use precautions

1. DO NOT SIT OR STAND ON THIS ITEM.
2. This product is not a toy. Do not allow children to play with or near this item.
3. Do not exceed specified weight capacities.
4. Use only on a flat, level, hard, and smooth surface that can safely support a fully loaded Storage Drawers.
5. Use as intended only.
6. Inspect before every use; do not use if parts are loose or damaged.

SAVE THIS MANUAL


PRODUCT PARAMETER

Model	3323	3323-W	3324-W
Total Product Quantity	2	1	1
Number Of Drawers	3/Each Style	3	4
Product Size	335×440×565mm	335×440×615mm	335×440×790mm

PARTS LIST


3323







3323-W






3324-W






Mo


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6



Step 7




Step 8




Model:3323-W **ASSEMBLY STEP**


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6



Step 7




Step 8




Model:3324-W **ASSEMBLY STEP**


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6



Step 7



Step 8



⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!

